

#### **GPU Teaching Kit**

**Accelerated Computing** 



Module 13.1 - GPU as Part of the PC Architecture

GPU as Part of the PC Architecture

## Objective

- To understand the major factors that dictate performance when using GPU as a compute co-processor for the CPU
  - The speeds and feeds of the traditional CPU world
  - The speeds and feeds when employing a GPU
  - To form a solid knowledge base for performance programming in modern GPU's



## Review - Typical Structure of a CUDA Program

Global variables declaration Function prototypes - \_\_global\_\_ void kernelOne(...) Main () allocate memory space on the device – cudaMalloc(&d\_GlblVarPtr, bytes ) - transfer data from host to device - <a href="mailto:cudaMemCpy(d\_GlblVarPtr">cudaMemCpy(d\_GlblVarPtr</a>, <a href="mailto:h\_Gl...)</a> execution configuration setup repeat - kernel call - kernelOne < < execution configuration >>> ( as needed args...); transfer results from device to host - cudaMemCpy(h\_GlblVarPtr,...) optional: compare against golden (host computed) solution - Kernel - void kernelOne(type args,...) - variables declaration - \_\_local\_\_\_, \_\_shared\_\_\_ automatic variables transparently assigned to registers or local

memory

- syncthreads()...


## Bandwidth – Gravity of Modern Computer Systems

- The bandwidth between key components ultimately dictates system performance
  - Especially true for massively parallel systems processing massive amount of data
  - Tricks like buffering, reordering and caching can temporarily defy the rules in some cases
  - Ultimately, the performance falls back to what the "speeds and feeds" dictate




#### Classic PC architecture

- Northbridge connects 3 components that must communicate at high speed
  - CPU, DRAM, video
  - Video also needs to have 1<sup>st</sup>class access to DRAM
  - Previous NVIDIA cards are connected to AGP, up to 2 GB/s transfers
- Southbridge serves as a concentrator for slower I/O devices




## (Original) PCI Bus Specification

- Connected to the Southbridge
  - Originally 33 MHz, 32-bit wide, 132 MB/second peak transfer rate
  - More recently 66 MHz, 64-bit, 528 MB/second peak
  - Upstream bandwidth remain slow for device (~256 MB/s peak)
  - Shared bus with arbitration
    - Winner of arbitration becomes bus master and can connect to CPU or DRAM through the Southbridge and Northbridge`



# PCI as Memory Mapped I/O


- PCI device registers are mapped into the CPU's physical address space
  - Accessed through loads/ stores (kernel mode)
- Addresses are assigned to the PCI devices at boot time
  - All devices listen for their addresses






# PCI Express (PCIe)

- Switched, point-to-point connection
  - Each card has a dedicated "link" to the central switch, no bus arbitration
  - Packet switches messages form virtual channel
  - Prioritized packets for QoS
    - E.g., real-time video streaming



#### PCIe 2 Links and Lanes

- Each link consists of one or more lanes
  - Each lane is 1-bit wide (4 wires, each 2-wire pair can transmit 2.5Gb/s in one direction)
    - Upstream and downstream now simultaneous and symmetric
  - Each Link can combine 1, 2, 4,
    8, 12, 16 lanes- x1, x2, etc.
  - Each byte data is 8b/10b encoded into 10 bits with equal number of 1's and 0's; net data rate 2 Gb/s per lane each way
  - Thus, the net data rates are 250 MB/s (x1) 500 MB/s (x2), 1GB/s (x4), 2 GB/s (x8), 4 GB/s (x16), each way




## 8/10 bit encoding

- Goal is to maintain DC balance while have sufficient state transition for clock recovery
- The difference of 1s and 0s in a 20-bit stream should be ≤ 2
- There should be no more than 5 consecutive 1s or 0s in any stream

- 00000000, 00000111, 11000001
   bad
- 01010101, 11001100 good
- Find 256 good patterns among 1024 total patterns of 10 bits to encode an 8-bit data
- 20% overhead


#### PCIe PC Architecture

- PCIe forms the interconnect backbone
  - Northbridge and Southbridge are both PCIe switches
  - Some Southbridge designs have built-in PCI-PCIe bridge to allow old PCI cards
  - Some PCIe I/O cards are PCI cards with a PCI-PCIe bridge
- Source: Jon Stokes, PCI Express: An Overview
  - http://arstechnica.com/articles/p aedia/hardware/pcie.ars





### GeForce 7800 GTX Board Details



**16x PCI-Express** 

**256MB/256-bit DDR3**600 MHz
8 pieces of 8Mx32


#### PCIe 3

- A total of 8 Giga Transfers per second in each direction
- No more 8/10 encoding but uses a polynomial transformation at the transmitter and its inverse at the receiver to achieve the same effect
- So the effective bandwidth is double of PCIe 2



## PCIe Data Transfer using DMA

- DMA (Direct Memory Access) is used to fully utilize the bandwidth of an I/O bus
  - DMA uses physical address for source and destination
  - Transfers a number of bytes requested by OS
  - Needs pinned memory
  - DMA hardware is much faster than CPU software and frees the CPU for other tasks during the data transfer



## **Pinned Memory**

- DMA uses physical addresses
- The OS could accidentally page out the data that is being read or written by a DMA and page in another virtual page into the same location
- Pinned memory cannot not be paged out

- If a source or destination of a cudaMemCpy() in the host memory is not pinned, it needs to be first copied to a pinned memory – extra overhead
- cudaMemcpy is much faster
   with pinned host memory
   source or destination

# Allocate/Free Pinned Memory (a.k.a. Page Locked Memory)

- cudaHostAlloc()
  - Three parameters
  - Address of pointer to the allocated memory
  - Size of the allocated memory in bytes
  - Option use cudaHostAllocDefault for now
- cudaFreeHost()
  - One parameter
  - Pointer to the memory to be freed



# **Using Pinned Memory**

- Use the allocated memory and its pointer the same way those returned by malloc();
- The only difference is that the allocated memory cannot be paged by the OS
- The cudaMemcpy function should be about 2X faster with pinned memory
- Pinned memory is a limited resource whose over-subscription can have serious consequences

## Important Trends

- Knowing yesterday, today, and tomorrow
  - The PC world is becoming flatter
  - CPU and GPU are being fused together
  - Outsourcing of computation is becoming easier...





#### **GPU Teaching Kit**

**Accelerated Computing** 





The GPU Teaching Kit is licensed by NVIDIA and the University of Illinois under the Creative Commons Attribution-NonCommercial 4.0 International License.